


# EZ-FILL



**EZ-Fill System has a built in check valve to prevent water in baptistery from entering incoming water line.**

**Press one button and walk away. The EZ-Fill system will do the rest.**

Designed with your comfort in mind, the EZ-Fill system is a great addition to any baptistery. The system interface module plugs into the heater control box. Press one button to activate the system. Once the EZ-Fill system fills the baptistery it will automatically turn the pump and heater on.



**EZ-Fill System will only work with PBH 5500 and 11K Heater Shown**

**Do you leave water in your baptistery for long periods of time?  
EZ-Fill system will automatically keep the baptistery filled to the correct level.**



System Interface Module powered by heater. Plug Module into Heater Control Box



**PIEDMONT**  
COMPOSITES & TOOLING